


# AS-Interface Slaves

## SIRIUS Pushbuttons and Indicator Lights

### AS-Interface F adapter for EMERGENCY STOP Operator

#### Overview



The AS-Interface F adapter is used for connecting the EMERGENCY STOP devices of the SIGNUM 3SB3 series to AS-Interface.

#### Design

The F adapter has a safe AS-Interface slave and is snapped onto the back of the EMERGENCY STOP device that is not included in the scope of supply.

Connection is via the AS-Interface shaped cable using the insulation piercing method.

Addressing is via the AS-Interface connections or via the built-in addressing socket.

#### Ordering data

#### Order No.

#### List Price \$

#### AS-Interface F adapter, for EMERGENCY STOP control unit SIGNUM 3SB3<sup>1)</sup>

AS-Interface F adapter for panel mount estop

2 Safe inputs/screw

**3SF5 402-1AA03 180.00**

2 Safe inputs/spring

**3SF5 402-1AA04 180.00**

2 Safe inputs and 1 out/screw

**3SF5 402-1AB03 200.00**

2 Safe inputs and 1 out/screw

**3SF5 402-1AB04 200.00**

#### EMERGENCY STOP operator

**3SF3 500-1HA20 23.00**

1) The EMERGENCY STOP control unit is not included in the scope of supply. For more information on the EMERGENCY OFF control unit, see Section *Pushbuttons and Light Indicators* in this catalog.